

# **Small Form-Factor Pluggable Copper Range Extender Module**

### **CL-SFP**







The ComNet<sup>™</sup> CopperLine<sup>®</sup> CL-SFP is a small form-factor pluggable Ethernet extender module that improves bandwidth and distance of existing copper networks. It helps avoid installation costs of new fiber lines on site by allowing full 100Mbps Ethernet bandwidth to be extended over 2-wire twisted pair or coaxial cable.

Housed in a small form-factor pluggable (SFP) module enclosure, it is designed for plug-and-play installation into any 100BASE-FX Ethernet unit with an MSA-compliant port. These must be used in pairs, with a CL-SFP module installed at both ends of the connection, or a CopperLine unit installed at one end.

#### **FEATURES**

- > Point-to-point Ethernet connectivity up to 2,000 ft (609 m) at 100Mbps.
- > Extends Ethernet distance over single pair or coax with an adapter.
- > Small Form-Factor Pluggable (SFP) module can be plugged into any Ethernet switch with SFP ports that support 100BASE-FX\*
- › Lifetime Warranty

#### **APPLICATIONS**

- > Retrofit existing analog CCTV installations to Ethernet-based systems
- > CCTV systems for Casinos, airports, school campuses
- \* The ComNet Copperline CL-SFP modules are fully compliant with all ComNet Ethernet products supporting 100BASE-FX SFP modules. Please contact ComNet technical support before purchasing this product if you intend to use it with any other 3rd party manufacturer in order to check compatibility.

# **Small Form-Factor Pluggable Copper Range Extender Module**

## **INSTALLATION & OPERATION**

CL-SFP is a book-end solution that can work only with an additional CL-SFP or ComNet<sup>™</sup> CopperLine<sup>®</sup> unit.

Follow the instructions below to install and connect CL-SFP:

Plug one of the two CL-SFP n the pair into the 100BASE-FX SFP slot of a device/switch. Repeat this step for the second CL-SFP in the pair.

#### Connection

Connect CL-SFP devices using a twisted 2-wire cable (use pins 1 & 2) or Coax

Always connect CL-SFP to another CL-SFP device or a ComNet<sup>™</sup> CopperLine<sup>®</sup> unit. If an CL-SFP was connected to a regular port of any Ethernet device, such as a switch, reset the CL-SFP by unplugging and re-inserting the unit.

Link synchronization may take up to one minute.

LED Indicators Use 100BaseFX LED on the host

### **SPECIFICATIONS**

#### Interface

	Туре	100BaseFX
	Connector	SFP / MSA Compliant
	Connectors	RJ-45
	Data Rate	100Mbps
Mechanical		
	Power	3.3V
	Power Consumption	1.0W
	Dimensions (H x W x L)	$0.48 \times 0.55 \times 2.91$ in (12.4 × 14.0 × 74.1 mm)
	Weight	1.06 oz (30.0g)

#### **Environmental**


Operating Temp	-40°C to +75°C
Storage Temp	-40°C to +85°C
Relative Humidity	0 to 90%, non-condensing

### ORDERING INFORMATION

Part Number	Description
CL-SFP3	100Mbps Copper Range Extending SFP, Local
CL-SFP4	100Mbps Copper Range Extending SFP, Remote
CLRJ2COAX	Adapter for RJ-45 to COAX
CLESP	Single Port Ethernet Surge Protector
Optional Accessories	RJ-45 Breakout Wiring Kit (Includes cable and terminal block)



# TYPICAL APPLICATION



#### **C** Low Power Consumption



3 CORPORATE DRIVE | DANBURY, CONNECTICUT 06810 | USA | T: 203.796.5300 | F: 203.796.5303 | TECH SUPPORT: 1.888.678.9427 | INFO@COMNET.NET 8 TURNBERRY PARK ROAD | GILDERSOME | MORLEY | LEEDS, UK LS27 7LE | T: +44 (0)113 307 6400 | F: +44 (0)113 253 7462 | INFO-EUROPE@COMNET.NET © 2014 Communication Networks. All Rights Reserved. "ComNet" and the "ComNet Logo" are registered trademarks of Communication Networks. 16 Jan 2014